

Technical Manual and Operating Instructions

Ultrasonic Thickness Gauges

MiniTest 430 / 440



Important Note

In ultrasonic thickness measurement it is inherent to the measuring procedure that the gauge might use the second echo rather than the first one reflected from the material being measured. This may result in a thickness reading **TWICE** as high than the actual thickness.

When measuring through extremely thick coatings in the echo-echo mode, it may occur that the thickness of coating layer is measured instead of the wall thickness that actually was intended to be measured.

The responsibility for proper use of the gauge and recognition of this phenomenon rests solely with the user of the gauge.

© Editon 1, 08/2014
Version 1.0
Subject to change without notice.

ElektroPhysik
Dr. Steingroever GmbH & Co. KG
Pasteurstr. 15
50735 Koeln, Germany

Phone: +49 221 752040
Fax : +49 221 7520467
Internet: <http://www.elektrophysik.com/>
Mail: info@elektrophysik.com

Table of Contents

1. Introduction	5
1.1 Important Notes on Wall Thickness Measurement	5
Prerequisites for the use of ultrasonic wall thickness gauges	5
1.1.1 Training of the Person in Charge of Testing	6
1.1.2 Limitations to Ultrasonic Testing	6
1.1.2.1 Ultrasonic Wall Thickness Testing	6
1.1.2.2 Influence of the Material to be tested	7
1.1.2.3 Influence of Changes in Temperature	7
1.1.2.4 Measurement of the Residual Wall Thickness	7
1.1.2.5 How to use the Couplant	7
1.1.2.6 Duplication of Reading	8
2. Technical Specifications	9
3. Measuring Principle	10
4. Description of the Gauge and Schedule of Supply	11
4.1 Description of the Gauge (Front and back Side)	11
4.2 Supply Schedule	11
4.2 Display	12
4.3 Keyboard	13
5. Preparing Measurement	14
5.1 Preparing the Gauge	14
5.2 Selection of the Transducer	14
5.3 Preparing the Surface of Measuring Object	15
6. Operation	16
6.1 Switch ON	16
6.2 Taking Readings	16
6.3 Calibration	17
6.3.1 Calibration	17
How to calibrate MiniTest 430 / 440	17
6.3.2 Determination of the Sound Velocity	17
6.3.2.1 How to determine the Sound Velocity	18
6.3.3 Calibration of the Transducer	18
6.4 User Menu	19
6.4.1 Measuring Mode (Meas. Mode)	19
6.4.1.1 MiniTest 430	19
6.4.1.2 Operating modes of MiniTest 440	21
6.4.1.2.1 I-E mode	21
6.4.1.3.2 Echo-Echo mode	22
6.4.2 Sound Velocity	23
6.4.2.1 Materials	23
6.4.2.2 Setting Sound Velocity (vel. custom)	24
6.4.3 Measuring Unit	25
6.4.4. Data Memory	25
6.4.4.1 Select a Batch (MiniTest 430 / 440)	26
6.4.4.2 Delete a Batch (MiniTest 430 / 440)	26
6.4.5 Gain Setting	27
6.4.6 Switch Off Mode	27
6.4.7 Contrast	28
6.4.8 Language	28
6.4.9 Gauge Data	28
6.4.10 Standard Setting	28
6.5 Data Processing	28

6.6 Storing Readings.....	28
7. Measuring Technology	29
7.1 Measuring Methods.....	29
7.2 Measurement on Pipes and Tubes.....	29
8. Maintenance and Precautions.....	30
8.1 Power Check.....	30
8.2 Precautions	30
8.2.1 General Precautions	30
8.2.2 Precautions to take during Measurement.....	30
9. Table of Materials and their typical Sound Velocity (Longitudinal Wave)	31
10. Safety Notes	32
11. Declaration of Conformity	33
11. After-Sales Service	33
13. Change History	33

1. Introduction

The MiniTest 420 and 440 model are non-destructive ultrasonic thickness gauges for portable or stationary use. Working according to the ultrasonic principle it enables quick and easy measurement of wall thickness. It can also be used for the measurement of the sound velocity of metals and various other materials.

Prior to use, please read the operating instructions carefully in order to get familiar with the use and all functionalities of the MiniTest 430/440 gauges.

Even if you are already familiar with measurement according to the ultrasonic principle, it is highly recommended to read section 1.1 carefully. This section provides important information on the limitations to and conditions for reliable wall thickness measurement such as technical training, required knowledge on the specific requirements for testing and the selection of a suitable test equipment.

The gauge is easy to use. To enable its quick use, please read the sections below to get familiar with the preparatory requirements and basic functions.

1.1 Important Notes on Wall Thickness Measurement



Before using the wall thickness gauge, please read the following instructions carefully. Make sure to fully understand and follow the instructions in order to avoid errors that might lead to erratic readings. Any decisions based on erratic readings may cause damage to property or personal injury.

Prerequisites for the use of ultrasonic wall thickness gauges

This manual contains essential information on how to operate your measurement device. In addition, there are a number of other factors to influence measurement. A detailed description of all such factors would be beyond the scope of this manual. For that reason, this manual is limited to the three most important requirements for reliable ultrasonic wall thickness measurement:

- adequate training of the person in charge of measurement
- fundamental knowledge on the specific requirements on and limitations to the measuring technique used for testing
- choice of a suitable measuring equipment

1.1.1 Training of the Person in Charge of Testing

The proper use of ultrasonic test equipment requires an adequate training in the field of ultrasonic wall thickness testing. Such training should include the following subjects:

- theory of sound propagation in materials
- effect of the sound velocity inherent to material to be tested
- behaviour of sound waves at the interfaces between different materials
- propagation of the sound beam in the material
- effect of the surface quality of the material to be tested

Insufficient knowledge on the above topics may result in erratic readings and thus lead to unforeseen consequences. For more information on the availability of training opportunities for examiners in ultrasonic testing, qualifications and certificates, please contact your national NDT partner, or, in Germany Deutschen Gesellschaft für Zerstörungsfreie Prüfung e.V., Motardstraße 54, D-13629 Berlin.

1.1.2 Limitations to Ultrasonic Testing

The results obtained from measurement solely relate to areas of the measuring object that have been targeted by the sound beam. Conclusions to other areas of the measurement object are not admissible. They are only allowed if extensive experience on the process of manufacture of the measuring objects is available and if appropriate methods of statistical evaluation can be applied. It should be taken into consideration that the ultrasound beam might be completely reflected by interfaces being present in the measuring object so that deeper reflection points will not be reached by the ultrasound any more. For that reason it must be ensured that all areas of the measuring objects to be measured can be reached by the sound beam.

1.1.2.1 Ultrasonic Wall Thickness Testing

Ultrasonic wall thickness measurement is based on the measurement of travel times of sound pulses in the object to be measured. For reliable wall thickness measurement it is presumed on the assumption that the velocity in the measuring object remains constant. Generally, this is given for the majority of work-pieces made of steel. Even if they include different alloy components, the sound velocity changes will be small enough to be neglected (unless high-precision measurement is required).

In other materials such as non-ferrous metals or plastics, the sound velocities are subject to major changes that might impair the measuring accuracy.

1.1.2.2 Influence of the Material to be tested

Material discontinuities may lead to strong variations of the sound velocity within a measuring object. In such case, an average sound velocity should be used for testing.

However, the best results will be obtained when calibrating the gauge by means of a reference sample. This sample must be made of the same material as the object to be measured and should exhibit plane parallel surfaces. Its thickness should equal the maximum thickness of the later object to be measured. Please note that any heat treatment might considerably change the sound velocity and thus influence the measuring precision accordingly.

If dramatic changes of the sound velocity are to be expected, it is recommended to readjust the sound velocity within shorter time intervals. This is to avoid erratic readings.

1.1.2.3 Influence of Changes in Temperature

The sound velocity is also influenced by the temperature prevailing in the material. If the gauge has been adjusted to a “cold” reference sample and wall thickness measurement is made on a “warm” object, major measuring errors are very likely to occur.

To avoid such measuring errors, it is recommended to use a temperature-adapted reference sample for adjusting the gauge. Another option would be to correct for the applicable temperature influence by means of the sound velocity/temperature correction table.

1.1.2.4 Measurement of the Residual Wall Thickness

Measuring the residual wall thickness of internally eroded or corroded objects such as tubes, containers or reaction vessels makes it necessary to choose a most suitable test equipment and to handle the sensor with utmost care. In addition, the nominal wall thickness as well as the suspected degree of wall thickness loss should be known.

1.1.2.5 How to use the Couplant

Make sure the user is familiar with the use of couplant. For each measurement, the couplant must be applied evenly over the surface of the measuring object. Any variations in couplant layer thickness will influence measuring accuracy. Both, adjustment of the gauge and wall thickness measurement must be made under the same coupling conditions. Make sure to use a quantity of couplant as small as possible and to apply a constant contact pressure of the sensor.

When measuring on curved surfaces such as pipes or tubes make sure the coupling of the transceiver is made properly. The acoustic layer interface of the transceiver must be aligned so as to form a right angle to the axis of curvature of sample (longitudinal axis of tube). For small tube diameters it is recommended to carry out two measurements: one with the layer interface in vertical position to the longitudinal axis of tube, another one in parallel position to the longitudinal axis of tube. The smaller of the two readings obtained should be used as the correct one for this measuring spot.



1.1.2.6 Duplication of Reading

Do not measure in a range lower than the measuring range specified for the sensor. In such case, the first back wall echo would not be strong enough for being processed whereas the amplitude of the second one would be strong enough to be processed accordingly. As a result, the reading obtained would be twice the actual wall thickness. In order to avoid such errors when measuring at the limit of the measuring range it is recommended to verify results by using another sensor.

In critical cases, it is recommended to use display screen equipment to provide additional information on the echo curve.

2. Technical Specifications


Display screen:	128 x 64 pixel dot matrix LC display, backlit
Digital display:	four-digits
Measuring range:	0.65 mm ... 500.0 mm (steel) depending on transducer
Display resolution:	0.1 mm (if readings > 100 mm) 0.01 mm (if readings < 100 mm)
Measuring accuracy:	0.65 mm... 9.99 mm: ± 0.04 mm 10 mm... 99.99 mm: $\pm (0.04 \text{ mm} + 0.1\% \text{ of reading})$ 100 mm... 500 mm: $\pm (0.3 \% \text{ of reading})$
Sound velocity:	1000...9999 m/s
Data memory:	10 batches for a maximum of 500 readings per batch
Measuring frequency:	2 readings/second in the standard mode 10 readings/second in the high-performance mode (scan)
Zero point calibration:	automatic
Auto switch-off:	2 minutes, 5 minutes or shut down manually
Power supply:	2 x AA battery, battery life 80 h in continuous operation
Operating temperature:	-20°C ... 50°C
Storage temperature:	-25°C ... 60°C
Dimensions:	130 x 73 x 24 mm
Weight:	190 g (without batteries)
Options	Transducers U2.0, U5.0, U7.5, U10.0, U5.0HT

3. Measuring Principle

The ultrasonic sensor head emits an ultrasonic signal to travel through the sensor head, the couplant and finally to the measuring object. A portion of the ultrasound signal is reflected from the surface of measuring object, another one is reflected from the opposite side of the object when travelling back. The sensor receives both echoes. The wall thickness is calculated according to the exact time of travel of pulse and shown as reading on display.

4. Description of the Gauge and Schedule of Supply

4.1 Description of the Gauge (Front and back Side)






1. display
2. keyboard
3. battery compartment (back panel)
4. name plate (back panel)
5. transducer socket (Identify PIN)
6. USB interface (MiniTest 430 / 440)

4.2 Supply Schedule







1. 1 x plastics carrying case
2. 1 x MiniTest gauge (model 430 or 440)
3. 1 x ultrasonic transducer (U5.0 for MiniTest 430; U5.0E for MiniTest 440)
4. 1 x couplant (gel, 200ml)
5. 1 x operating instructions (German / English / French)
6. 1 x CD with data transfer software
7. 1 x USB connecting cable
8. 2 x 1,5V (AA) batteries


4.2 Display



1. active batch and number or readings stored in this batch
2. transducer model
3. battery state
 -  fully charged
 -  empty
4. measuring mode
5.  measuring icon and measuring unit
6. gain mode of amplifier selection (A = Auto, L= Low , M = Medium, H = High).
7. sound velocity selection
8. current reading

4.3 Keyboard

	ON / OFF button
	Menu key Press to enter the operating menu
	Arrow UP/DOWN keys Press UP/DOWN to scroll through the different menu options. Press arrow UP to enable / disable the backlight.
	OK/ESC key Press OK to confirm a selection in the menu. Press ESC to quit the menu.
	CAL key Quick access for sound velocity calibration (it is required the wall thickness is known).
	Data memory short-cut key



5. Preparing Measurement

5.1 Preparing the Gauge

Please check gauge and accessories immediately upon receipt. For the supply schedule, please refer to section 4.1.2 of this manual. Please contact your supplier in case delivery is not complete or does not comply with the supply schedule you have ordered. Any damage of the gauge should be reported upon delivery. Do not use the gauge in case it seems to be damaged!

5.2 Selection of the Transducer

Type	Frequency	Measuring range	Temperature
U2.0	2,0 MHz	2.0 mm...400 mm	< 50°C
U5.0E	5,0 MHz	E-E 3.0 mm...25 mm I-E 1.44 mm...200 mm	< 50°C
U5.0	5,0 MHz	0.8 mm...300 mm	< 50°C
U5.0HT	5,0 MHz	2.0 mm...200 mm	< 350°C
U7.5	7,5 MHz	0.65 mm...50 mm	< 50°C
U10.0	10,0 MHz	0.65 mm...20 mm	< 50°C

Make sure to select a suitable transducer according to the thickness of your measuring object. The transducer used for measurement must be in a good condition. Make sure transducer tip and coupling surface are not worn off. The measuring range of transducer should cover the complete wall thickness range to be measured (application range). The temperature of measuring object must not exceed the temperature range specified for the transducer you have selected.

Transducer type	Application
U5.0: (5.0 MHz)	Standard transducer for MiniTest 430 to cover a wide range of applications such as measurement on - flat surfaces - large curvature radii - objects with a thickness > 50 mm
U5.0E (5.0 MHz)	Standard transducer for MiniTest 440. When connected to MiniTest 440, this transducer is able to measure in the E-E mode the wall thickness of steel through a coating applied to the steel.
U2.0 (2.0 MHz)	Rough surfaces, such as on cast components
U5.0HT (5 MHz)	Suitable for temperatures < 350°C
U7.5 (7,5 MHz)	Thin wall thickness and small curvature radius
U10.0 (10 MHz)	Thin wall thickness and small curvature radius (small geometries)
U2.0 (2.0 MHz)	Rough surfaces, such as on cast components


5.3 Preparing the Surface of Measuring Object


Very rough and/or corroded surfaces should be pre-treated as follows:

1. Smoothen the surface by grinding, polishing or filing or use a high-viscosity couplant.
2. Apply some couplant to the surface of measuring object.
3. Take several readings around the measuring spot.

6. Operation

6.1 Switch ON

Connect the transducer to the gauge socket. Press the ON/OFF button  to switch on. The following appears on display:



If no transducer has been connected prior to switch ON, the following message will appear: "Please insert the transducer". Insert the transducer into the gauge socket and wait for the measuring status to appear.



Please make sure to connect solely original ElektroPhysik transducers suitable for MiniTest 430 / 440. Otherwise, the gauge will not work correctly and the error message "ERROR" will appear.

6.2 Taking Readings

There are two options to access the measuring mode:

1. Connect transducer and switch on the gauge.
2. From the menu you can press ESC and go back to the measuring mode.



Once you have put the transducer onto the measuring object, the display will show the measuring icon to indicate the coupling action. Once the reading has stabilized, you can detach the transducer from the measuring object. Remove the transducer in a quick action. The last reading taken appears on display.

6.3 Calibration

Errors occurring during the first operating steps might be due to the following reasons:

- Transducer failure or strong variations in temperature
- System error caused by base unit / transducer incompatibility
- Computing error caused by sound velocity/material setting error


For troubleshooting please proceed as follows:

Press  -key followed by  or  to select a suitable option.

6.3.1 Calibration

How to calibrate MiniTest 430 / 440

Worn off transducer or the use of different transducer models as well as the ambient temperature may lead to erratic readings. To compensate for such errors, the both models feature an “automatic calibration”.



Important note:




Prior to calibration make sure the transducer tip is clean and free from any residual couplant or other dirt particles that might impair measurement and thus the calibration accuracy. In case temperature varies strongly during measurement, it is recommended to use the calibration function more frequently in order to ensure accuracy of measurement.


6.3.2 Determination of the Sound Velocity

The sound velocity in the measuring object depends on the material the object is made of. In addition, measuring objects might exhibit material irregularities (if produced in different product batches). As a result, the sound velocity might vary according to the sample to be tested. To prevent measuring errors based on divergent sound velocities, it is absolutely necessary to determine the precise sound velocity of an object unless measuring errors are small enough to be neglected. To calibrate the gauge to the correct sound velocity of an object, the function “Sound velocity” is available.

6.3.2.1 How to determine the Sound Velocity

1. Select a stored sound velocity or set the gauge to a sound velocity as close as possible to the sound velocity of the material to be measured.
2. Take a sample of a defined thickness as close as possible to the thickness of the later measuring object. If no such sample is available, take your measuring object and measure its thickness using a caliper or another measuring tool.
3. Now use MiniTest 430 or 440 to measure the sample in order to get a thickness value.

4. First press  -key to go to the "Sound velocity". Then press  or  in order to adjust to the thickness reading you have measured and get the correct sound velocity accordingly.








5. Adjust the sound velocity so that the material thickness shown on display corresponds to the measured thickness of sample.
6. Re-measure the sample and check the deviation between reading and actual thickness. If both values are identical, the sound velocity is correct for this material.

6.3.3 Calibration of the Transducer




The transducer calibration function is to be used to compensate for errors or system errors that cannot be remedied by "Automatic calibration". The cause of such error might be for instance a transducer change. First make sure the error is not due the setting of an unsuitable sound velocity. To carry out the transducer calibration please proceed as follows:

1. Adjust the gauge to the sound velocity 5920 m/s.
2. Take a reading on test block supplied with the gauge and take. The reading obtained should be 4.00 mm \pm 0.01 mm. If the reading obtained differs from that value, press the

 -key. Then press  or . Choose "Transducer calibration" and press OK to confirm.

Now use arrow keys  or  to adjust the reading you obtained to the thickness of test block, i.e. 4.00 mm. Press OK to confirm the value. Then press ESC to go to the measuring mode.


6.4 User Menu

Press  key to go to the main menu. Use arrow keys  or  to scroll up/down the menu items.

Once your selected item appear press OK to confirm.

Press ESC to quit the menu and to go to the measuring mode.

MiniTest 430 / 440



6.4.1 Measuring Mode (Meas. Mode)

6.4.1.1 MiniTest 430

The gauge offers 5 different measuring modes. Please select the correct mode according to your requirements and measuring conditions.

Standard mode: The current reading is shown. This mode applies if you are satisfied with the standard measuring needs.

Minimum mode: In this mode, the lowest values is shown during measurement. This mode is recommended for curved surfaces or if it is required to indicate the lowest thickness values. This would be a typical application of tube measurement.


Important note: This mode is NOT recommended for cast iron or Aluminium alloys.

Difference mode: If you have adjusted a set point previously, this mode will indicate the difference between the current reading and set point. This mode is particularly suitable for quality inspection and if it is required to identify the products within the admissible thickness tolerance range.

Alarm mode (Limitation): In this mode, a visual alarm will be given once the upper or lower limit (if set previously) has been exceeded. This mode enables a quick and easy checking of readings so that a permanent monitoring of readings will not be necessary. In practical operation, this mode is more frequently used than the “Difference mode”.

Scan mode (high-performance mode): This mode is particularly suited for measurement on high-temperature samples.

The different modes are shown on display as follows:



6.4.1.2 Operating modes of MiniTest 440

This gauge offers two different operating modes:

<ul style="list-style-type: none">• I-E: Impulse-Echo mode (pulse-echo)	Available with all transducer models.
<ul style="list-style-type: none">• E-E: Echo-Echo mode	Only available with the U5.0E transducer for the measurement of wall thickness through a coating.

6.4.1.2.1 I-E mode

The pulse-echo (I-E) mode offers five different measuring modes. Please select the correct mode according to your measuring requirements and conditions.

Standard mode: The current reading is shown. This mode applies if you are satisfied with the standard measuring needs.

Minimum mode: In this mode, the lowest values is shown during measurement. This mode is recommended for curved surfaces or if it is required to indicate the lowest thickness values. This would be a typical application of tube measurement.


Important note: This mode is NOT recommended for cast iron or Aluminium alloys.

Difference mode: If you have adjusted a set point previously, this mode will indicate the difference between the current reading and set point. This mode is particularly suitable for quality inspection and if it is required to identify the products within the admissible thickness tolerance range.

Alarm mode (Limitation): In this mode, a visual alarm will be given once the upper or lower limit (if set previously) has been exceeded. This mode enables a quick and easy checking of readings so that a permanent monitoring of readings will not be necessary. In practical operation, this mode is more frequently used than the "Difference mode".

Scan mode (high-performance mode): This mode is particularly suited for measurement on high-temperature samples.

The different modes are shown on display as follows:



6.4.1.3.2 Echo-Echo mode

The Echo-Echo (E-E) mode is able to measure between two successive back-wall echoes. This allows to measure the actual wall thickness through a coating. The thickness of the coating can be up to 1 mm.

Please note! This function for measuring the wall thickness through a coating is only available with the U5.0E transducer model.

6.4.2 Sound Velocity

The correct selection of the sound velocity is vital for accurate measurement. Different materials exhibit different sound velocities at which the ultrasound travels through. If you select the wrong sound velocity, measurement will be erroneous.

There are two ways to select the material's sound velocity: material selection and sound velocity setting.



Materials:

You select the sound velocity according to the material and the pre-set sound velocity.

Vel. Custom:

The sound velocity is user adjustable.

6.4.2.1 Materials

If the material and its specific sound velocity are known, users can select the sound velocity from the gauge accordingly. Nine (9) different velocities are stored in the gauge and can be selected by the user: Aluminium, titanium, steel, stainless steel, glass, copper, brass, polystyrene and nylon.


Note: The 9 velocities are just theoretical ones. To increase measuring accuracy, please refer to “Setting Sound Velocity” under 6.4.2.2. The sound velocity functionality enables you to set the gauge to the correct sound velocity of a material.



6.4.2.2 Setting Sound Velocity (vel. custom)


If none of the sound velocities as stored for the 9 materials meet your requirements, the sound velocity can be adjusted individually. Please refer to the table given in the appendix, section 9 of this manual. Use this table to set to the correct sound velocity as requested.

Note: *For more accurate measurements, please refer to section 6.3.2.1 “How to determine the sound velocity”.*



6.4.3 Measuring Unit

Read-out resolution and measuring unit are user-adjustable. When selecting “High resolution”, the surface of measuring sample should smooth in order to obtain accurate readings.



Note:

For using the U5.0HT or U2.0 transducers, the following setting is recommended:

0.1 mm / 0.01 in.

6.4.4. Data Memory

Both models MiniTest 430 and 440 feature a data memory for storing a maximum of 10 batches with 500 readings storable per batch. Total data memory capacity is 5000 readings.

A batch memory includes the following data: readings, type of transducer head, sound velocity and selected measuring mode.

A batch can be selected and/or deleted.



6.4.4.1 Select a Batch (MiniTest 430 / 440)

Use this function to select a batch according to your requirements. Once a batch selected, it will become active and all readings taken will be stored to this batch.

Below a batch that has been selected but no readings have been taken so far.



Below a batch that has been selected and to which readings have been stored.




Please note:

If you have selected a batch to which readings have been stored and then change the transducer model or measuring mode, the following message will appear "Change batch". In such case the batch is not available as it has been defined with another transducer model and/or measuring mode. Please select another batch that matches the transducer model/measuring mode you are currently using.

6.4.4.2 Delete a Batch (MiniTest 430 / 440)

Use this function to delete a batch. First select the batch to be deleted, then confirm deletion.



Please note:

If you delete a batch, all data stored to this batch will be deleted and cannot be restored. For that reason it is recommended to previously save the data to be deleted to your PC.

6.4.5 Gain Setting

Measuring accuracy and consistency of readings are influenced by the material to be measured and its composition. In order to meet the requirements for accurate measurement, it is requested to set the gauge according to the special characteristics of a sample and measuring conditions.

For the majority of materials and conditions the auto gain adjustment will be sufficient whereas some specific measuring tasks might require specific gauge settings. For gain setting, the gauge offers four different working modes: Auto, Low, Medium and High.

Auto: This mode matches different transducers and is suitable for the majority of measuring requirements.

Low: Suitable for high scattering and materials exhibiting low attenuation properties.

Medium: Suitable for a large field of applications.

High: Suitable for high attenuation materials.



6.4.6 Switch Off Mode

Both models, MiniTest 430 and 440, offer three different service modes:

- after 2 min: automatic switch off after two minutes of idle state
- after 5 min: automatic switch off after five minutes of idle state
- disable: automatic switch off is disabled, the gauge is in continuous operation

Note:

When the automatic switch off has been disabled, make sure to switch off the gauge manually after use in order to save power.

6.4.7 Contrast

The gauge offers 6 levels for contrast setting.

6.4.8 Language

The gauge offers the following languages: Chinese, English, German, French.

6.4.9 Gauge Data

This option allows you to read out the following data:


- Gauge model
- Serial of gauge
- Transducer type
- Serial of transducer
- Software version of gauge

6.4.10 Standard Setting

For trouble shooting, it is recommended to use this function to reset the gauge to the factory settings.

6.5 Data Processing

Both models, MiniTest 430 and 440, offer two different data processing options.

Press the -key to get access to the two options:

- Data read: If you have selected a batch, the stored data will immediately be displayed on the screen.
- Data transfer: Via the USB interface, the stored data will be transferred to a PC.

Please note:

For a detailed description on data transfer to a PC via the USB interface please refer to the CD supplied with the gauge.

6.6 Storing Readings

Once you have selected a batch, readings can be stored to the gauge as follows:

1. Make sure readings have been taken correctly.
2. Once you lift the transducer from the sample, press OK to store the current reading.

7. Measuring Technology

7.1 Measuring Methods

The gauge provides four different measuring methods.

1. Single point measurement: use the transducer to measure any point of the measuring object. The reading shown is the thickness value.
2. Two point measurement (on cylindrical parts, e. g. pipes and tubs): perform two measurements on the same point of the surface of object. During the second measurement, make sure the black line on the transducer head (layer to separate the transmitter and receiver part of transducer) is oriented in a 90 degree position to the axis of the pipe or tube. The smaller of the two readings obtained represents the thickness value.
3. Multiple point measurement: perform several measurements on the measuring object within a range of about 30mm in diameter. The smaller of the readings represents the thickness of the measuring object.
4. Continuous measuring method: use the single point measuring method and take readings continuously along the designated route. The intervals between measurements should be less than 5mm. The smallest reading represents the thickness of the measuring object.

7.2 Measurement on Pipes and Tubes

During measurement, make sure to position the transducer's separating layer perpendicular or parallel to the longitudinal line of the pipe or tube. For pipes and tubes of large diameters, the separating layer of transducer should be perpendicular to the longitudinal line the measuring object whereas for small diameters, it is recommended to carry out measurement in both directions, perpendicular and parallel to the longitudinal line of the measuring object. The minimum readout represents the thickness of object at this measuring spot.



senkrecht parallel

perpendicular parallel

8. Maintenance and Precautions

8.1 Power Check

When the power is low, the low battery indicator appears. At this moment, users should replace the battery in time, or it will affect the measuring accuracy. Please note that the backlight will use additional power. If the battery is too low, the backlight will automatically shut down in order to ensure reliable service.

For use on site it is recommended to make available a set of replacement batteries.

Note: If the gauge is not in use for a longer period of time, make sure to remove the batteries in order to prevent battery leakage and damage to the gauge.

8.2 Precautions

8.2.1 General Precautions

Keep the gauge away from strong vibrations. Do not stock in an environment with increased levels of air humidity. To prevent cable damage, plug or unplug the transducer by holding the cable jacket.

8.2.2 Precautions to take during Measurement

1. Once you place the transducer on the measuring object, the measuring symbol appears on display (arrow down) to indicate the coupling action. As soon as the reading has stabilized, you can lift the transducer from the measuring object.
2. Make sure to remove the transducer immediately after a reading has been taken successfully as putting the transducer down again might cause erratic readings if big amounts of coupling agent are placed on the measuring object.
3. Please note: a worn off transducer will lead to unstable and erratic readings and should be replaced by a new one.

9. Table of Materials and their typical Sound Velocity (Longitudinal Wave)

Material	Sound velocity	
	in/ μ s	m/s
Air	0,013	330
Aluminium	0,250	6300
Aluminium oxide	0,390	9900
Beryllium	0,510	12900
Boron carbide	0,430	11000
Brass	0,170	4300
Cadmium	0,110	2800
Cast iron	0,180	4600
Crown glass	0,210	5300
Copper	0,180	4700
Glycerine	0,075	1900
Gold	0,130	3200
Ice	0,160	4000
Inconel	0,220	5700
Iron	0,230	5900
Lead	0,085	2200
Magnesium	0,230	5800
Mercury	0,057	1400
Molybdenum	0,250	6300
Monel	0,210	5400
Neoprene	0,063	1600
Nickel	0,220	5600
Nylon, 6.6	0,100	2600
Oil (SAE 30)	0,067	1700
Platinum	0,130	3300
Plexiglass	0,110	1700
Polyethylene	0,070	1900
Polystyrene	0,0930	2400
Polyurethane	0,0700	1900
Quartz	0,230	5800
Rubber, Butyl	0,070	1800
Silver	0,140	3600
Stahl stainless	0,228	5800
Steel, commercial	0,233	5920
Teflon	0,060	1400
Tin	0,130	3300
Titan	0,240	6100
Tungsten	0,200	5200
Uranium	0,130	3400
Water	0,584	1480
Zinc	0,170	4200







Please note: The actual sound velocities depend on the temperature, composition and treatment of a material. Especially metal alloys or plastic materials may exhibit strong variations. For that reason, all values stated in the table are approximate ones.

10. Safety Notes

Safe operation will be ensured as far as the instructions and notes in this manual and on the gauge are observed.

Prior to any installation work the power supply must be cut.

Please do only use original spare parts or accessories.

	<p>Storage batteries and accessories</p> <p>Make sure to use only original accessories and batteries supplied / recommended by the manufacturer of the gauge. Connect only to compatible peripheral devices.</p>
	<p>Connecting other devices</p> <p>If you connect the gauge to any other device, please refer to the respective instructions manual of such device for detailed information on safety issues. Do only connect original accessories.</p>
	<p>Keep away from water</p> <p>The measuring unit is not waterproof. Keep in a dry place.</p>
	<p>Keep away from explosion-hazardous area.</p>
	<p>Approved after-sales service</p> <p>The gauge may only be repaired by approved and qualified after-sales service personnel.</p>
	<p>Medical facilities</p> <p>Please ask for permission before using the gauge in medical facilities.</p>

11. Declaration of Conformity

We herewith declare that the gauges MiniTest 430 and MiniTest 440 are in conformity with the provisions of directive 89/ 336 / EEC (Electromagnetic compatibility), in Germany: EMVG (Gesetz über die elektromagnetische Verträglichkeit) of November, 9th, 1992.

11. After-Sales Service

The MiniTest 430 and MiniTest 440 gauges are manufactured according to state-of-the-art production methods under the use of high-quality components. Careful production controls along with a Certified Quality Management according to DIN EN ISO 9001 ensure optimum product quality.

Should you nevertheless notice any error, please contact the ElektroPhysik after-sales-service and advise your problem.

Please retain the original packing for future transportation needs if a repair should become necessary.

For more detailed information on the use, applications, service or technical data, please contact your local agent or ElektroPhysik:

ElektroPhysik
Dr. Steingroever GmbH & Co. KG
Pasteurstr. 15
50735 Koeln, Germany
Tel.: +49 221 75204-0
Fax: +49 221 75204-67
E-Mail: info@elektrophysik.com

Please refer to our website for the local representative of ElektroPhysik in your country:
www.elektrophysik.com

13. Change History

This section is to backtrack any changes and modifications to this manual. If no changes are available, this section shall remain empty.